



## FIRST USE SUPPLEMENT - YARIS GR CONTROLS

### Available Features & Activation

#### MAP SWITCHING

- A) Hold down the **CRUISE CONTROL CANCEL** button, located on the steering wheel.
- B) With the cruise control button still pressed, use the cruise control **PLUS+** and **MINUS-** buttons to toggle between maps.
- C) Your rev counter needle will point at alternative RPM's to highlight the individual maps available.

- 1,000 RPM: 95 Octane Calibration (Maximum Power in line with fuel type).
- 2,000 RPM: 98 Octane Calibration (Maximum Power in line with fuel type).
- 3,000 RPM: OEM Calibration (Standard Power)
- 4,000 RPM: Economy Mode (Reduced Power)

- D) When the desired MAP / Setting is indicated, **RELEASE** the **CRUISE CONTROL MINUS-** Button

#### LAUNCH CONTROL

**NOTE:** Launch control will only be allowed to function once the engine has reached the minimum operating temperature.

- A) Turn traction control fully off.
- B) Hold down the clutch pedal and engage first gear.
- C) Press the throttle pedal and hold engine at required RPM.
- D) Hold down **CRUISE CONTROL MINUS-** button.
- E) Hold the throttle pedal wide open (ECU will maintain the desired RPM, but will allow the turbo to build boost).
- F) Keep throttle pedal fully open and release clutch to launch.

#### ROLLING LAUNCH CONTROL

**NOTE:** Launch control will only be allowed to function once the engine has reached the minimum operating temperature.

- G) Whilst driving hold engine at required RPM.
- H) Hold down **CRUISE CONTROL MINUS-** button.
- I) Hold the throttle pedal wide open (ECU will maintain the desired RPM, but will allow the turbo to build boost).
- J) Keep throttle pedal fully open and release clutch to perform rolling launch.